



Gazebo Overview

Size Guide & Measurements

Gazebo setup dimensions:



Bar is modulated allowing the bar/entrance configuration to be an any way around.



- A. Roof width
- B. Roof length
- C. Ground to roof peak
- D. Ground to roof edge
- E. Bar height
- F. Bar width
- G. Stool height
- H. Gazebo opening width
- I. Gazebo width
- J. Gazebo with Bar width
- K. Suggested concrete pad width to leave room for Stools
- L. Suggested concrete pad length to leave room for Stairs